


Step-by-step installation instructions:

1. Apply AGNI-Black in the annular space to the depth of the AGNI-Board, 100mm (nominal) deep and finished flush with both faces of the AGNI-Board.
2. Make a 20x20mm fillet/cone of AGNI-Black applied on the unexposed face.



Technical Information

System ID	AE-225
Substrate	2 x layers of AGNI-Board in min. 120mm concrete floor/ceiling
Service range	FR Pair coil
Annular gap	4.7-12.6mm
AGNI-Products	AGNI-Black
Protection installation	Asymmetrical

Compliance Information

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/120/120
Reference	PF25041




8 Clare St Bayswater
VIC 3153, AUSTRALIA
+61 (03) 7045 4242
info@agnitek.com.au
www.agnitek.com.au

Disclaimer

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.

Date 10.06.2025



Technical Information

System ID	AE-225
Substrate	2 x layers of AGNI-Board in min. 120mm concrete floor/ceiling
Service range	FR Pair coil
Annular gap	4.7-12.6mm
AGNI-Products	AGNI-Black
Protection installation	Asymmetrical

Compliance Information

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/120/120
Reference	PF25041

Disclaimer

Agnitek reserves the right to modify product specifications without prior notice due to its ongoing research, development & certification programme. The information in this document is provided in good faith and is intended for guidance purposes only. Any accompanying drawings are solely for illustrative purposes. Since Agnitek cannot oversee installation methods or ensure site conditions, no warranties, expressed or implied, are intended regarding the products' actual performance. We do not accept liability for any loss, damage, or injury from using this information. Please take a look at the test reports displayed on a relevant AGNI-System webpage for all compliance specifics.



Agnitek[®]
FIRE RATED TECHNOLOGY

8 Clare St Bayswater
VIC 3153, AUSTRALIA
+61 (03) 7045 4242
info@agnitek.com.au
www.agnitek.com.au

Date 10.06.2025